



BRISBANE –W16

1. Runway Coordination:

Runway: No more than 50 runway movements in any 60 minute period measured in 15 minute intervals
No more than 25 arrivals in any 60 minute period or 7 arrivals in 15 minutes
No more than 30 departures in any 60 minute period

2. International Terminal:

Apron Parking at the International Terminal

3 aircraft up to 388 size
11 aircraft up to 744 size
3 positions are available for remote parking (2 x 744, 1 x 767 size)
Buffer between occupancies 15 minutes

Airlines that use maintenance facilities may have to move their aircraft from/to the International terminal

75 minutes (wide body) and 45 minutes (narrow body) after arrivals and before departures.

Maximum Passenger Arrival and Departure Rates

1400 inwards seats in any 30 minute period
2000 inwards seats in any 60 minute period

1350 outwards seats in any 30 minute period
1900 outwards seats in any 60 minute period

3. Domestic Common User Terminal:

Apron Parking at the Domestic Common User Terminal

7 aircraft up to 321 size

18 layover positions up to 320 size

Buffer between occupancies 15 minutes

Transit aircraft have a maximum dwell time of 50 minutes

Originating or Terminating aircraft have a maximum dwell time of 50 minutes

Maximum Passenger Arrival and Departures Rates

Separation between arrivals or departures 10 Minutes

Maximum arrivals 6 aircraft in 60 minutes

Maximum departures 5 aircraft in 60 minutes

AIRPORT COORDINATION AUSTRALIA

Level 3, Suite 1227, International Terminal (T1) Sydney International Airport, NSW 2020 Australia

P.O. Box 3047, Sydney International Airport, NSW 2020 Australia

T +61 2 93135469 F +61 2 93134210 E slots@airportcoordination.org W www.airportcoordination.org



BRISBANE-W16

4. General Aviation Terminal:

Apron Parking at the General Aviation Terminal:

- 3 aircraft up to GLEX size
- 9 aircraft up to Dash 8 – 300 size
- 9 aircraft up to Saab size

60 min Maximum occupancy time on bay per movement.

Maximum Passenger Arrival and Departures Rates

Curfew

Nil.

Local Time

UTC +10

AIRPORT COORDINATION AUSTRALIA

Level 3, Suite 1227, International Terminal (T1) Sydney International Airport, NSW 2020 Australia
P.O Box 3047, Sydney International Airport, NSW 2020 Australia

T +61 2 93135469 F +61 2 93134210 E slots@airportcoordination.org W www.airportcoordination.org