



## **GOLD COAST (OOL) – S23**

### **Apron Capacity**

9 x Code E MARS (1 x Code E or 2 x Code C)  
1 x Code C  
1 x Code E MARS (1 x Code E limited to A333/B789 size or 2 x Code C) remote stand with refuelling capability

15 minute buffer between occupancies

### **Maximum International Passenger Arrival Rate**

The maximum arrival capacity is 1,000 seats per hour. The following separation between arrivals is required:

Aircraft up to 180 seats    10 minutes before next arrival  
Aircraft up to 400 seats    20 minutes before the next arrival

Flights with another Australian port preceding or succeeding require 10 minutes before the next arrival

### **Maximum International Passenger Departure Rate**

The maximum departure capacity is 1,000 seats per hour. The following separation between departures is required:

Aircraft up to 180 seats    10 minutes after the previous departure  
Aircraft up to 400 seats    20 minutes after the previous departure

Flights with another Australian port preceding or succeeding require 10 minutes after the previous departure.

### **Curfew:**

23:00 to 06:00 local daily (no planned movement's 22:30 - 06:05 local)

### **Local Time:**

UTC+10

#### **AIRPORT COORDINATION AUSTRALIA**

Level 3, Suite 1297, International Terminal (T1) Sydney International Airport, NSW 2020 Australia

P.O Box 3047, Sydney International Airport, NSW 2020 Australia

T +61 2 93135469    F +61 2 93134210    E [slots@airportcoordination.org](mailto:slots@airportcoordination.org)    W [www.airportcoordination.org](http://www.airportcoordination.org)